

Nissin DIGITAL Compatibility Chart Last update: Aug 2018

Olympus Micro Four Thirds / Four Thirds Cameras

	E-M1 Mark II (OMD)	E-M1 (OMD)	E-M5 Mark II (OMD)	E-M5 (OMD)	E-M10 Mark III (OMD)	E-M10 Mark II (OMD)	E-M10 (OMD)	PEN-F	E-P5	E-P3	E-P2	E-P1	E-PL7	E-PL6	E-PL5	E-PL3	E-PL2	E-PL1	E-PM2	E-PM1	E-620	E-520	E-500	E-410	E-30
--	--------------------	------------	--------------------	------------	----------------------	---------------------	-------------	-------	------	------	------	------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	------

Nissin Model																										
Air 1 Commander (Four Thirds ver.)	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
D1700 A (Four Thirds ver.)	●	●	○	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
i60A (Four Thirds ver.)	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
i40 (Four Thirds ver.)	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
D1466 (Four Thirds ver.)	—	●	○	●	—	○	●	○	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●

- Compatible Model
- Incompatible Model
- No information available. To be confirmed.

*1 Unstable operation may appear when turn on the S-OVF Function (Optical view finder simulation) of EVF and shoot with EVF.
 *2 Flash's optical slave wireless mode is incompatible with camera's wireless flash system.

Nissin DIGITAL Compatibility Chart Last update: Aug 2018

Panasonic Micro Four Thirds Cameras *3

	GH5	GH4	GH3	GH2	GH1	GX8	GX7	GX7 Mark II / GX8S / GX80	GX1	G10	G9	G8 / G80 / G85	G7 / G70	G6	G5	G3	G2	G1	G2	GF1	LX100	LX7	LX5	LX3	FZ200
--	-----	-----	-----	-----	-----	-----	-----	---------------------------	-----	-----	----	----------------	----------	----	----	----	----	----	----	-----	-------	-----	-----	-----	-------

Nissin Model																										
Air 1 Commander (Four Thirds ver.)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
D1700 A (Four Thirds ver.)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
i60A (Four Thirds ver.)	●	—	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
i40 (Four Thirds ver.)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
D1466 (Four Thirds ver.)	—	●	●	●	●	○	●	○	●	●	—	—	○	●	●	●	●	●	●	●	●	●	●	●	●	●

- Compatible Model
- Incompatible Model
- No information available. To be confirmed.

*3 According to the specifications of Panasonic Lumix series, the continuous shooting function cannot be used when an external flash is installed on the hot shoe.

Fujifilm Cameras																														
	GFX 50s	X-H1	X-T2	X-T1 / X-T1 GS	X-T20	X-T10	X-Pro2	X-Pro1	X-E3	X-E2S	X-E2	X-E1	X-M1	X-A5 <small>New</small>	X-A3 <small>New</small>	X-A2	X-A1	X100F	X100T	X100S	X100	X70	X30	X20	X10	X-S1	HSS/EXR	HSS/EXR	HSS/EXR	
Nissin Model																														
Air 10s Commander <small>New</small>	—	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	—
Air 1 Commander	●*1 *2	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
Di700 A	●*1 *2	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
i60A	●*1 *2	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
i40	●*1 *2	●	●*1	●*1	●	●	●*1	●	●	●	●	●	●	○	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○

- Compatible Model
- Incompatible Model
- This camera supports HSS/FP High speed synchronize function.

*1 The Fujifilm camera is supporting of High speed synchronize function after camera firmware updated
 *2 Flash can be insert on the hot shoe of main body or that of EVF. When inserted a flash on the EVF shoe, do not tilt-up EVF since this may make the EVF damage.